



LED Switch Pod – JK '11 to current
INSTALLATION INSTRUCTIONS

3101 W. FM 544
Wylie, TX 75098
866.342.0977
BLKMTNJeep.com

Part #BMSP



READ INSTALLATION INSTRUCTIONS ENTIRELY PRIOR TO INSTALLING PRODUCT

- 1) Remove sun visor mounting screws (**Photo 1**)
- 2) Remove windshield corner trim. (**Photo 2**)
- 3) Pop lower A-Pillar trim from windshield frame. Using a small flat head screw driver, remove metal retainer clip from factory trim panel. DO NOT DISCARD. Clip will be reused. (**Photo 3**)
- 4) A second metal retainer clip will be needed for a new A-Pillar Pod.
- 5) Reinstall metal retainer clips onto new A-Pillar Switch Pod. Make sure clip is aligned with plastic tabs before pressing into place.
- 6) Run a box knife over cut lines several times before pressing blade through plastic. CAUTION: ALWAYS CUT AWAY FROM BODY. If needed, the cutting blade can be heated to aid in cutting plastic. (**Photo 4**)
- 7) Insert switch into cut opening. Trim opening as needed. Only remove enough material to allow switch to be installed. If too much material is removed the switch will be loose and result in poor fit. (**Photo 5 & 6**)
- 8) Place new switch pod to windshield frame making sure to align lower metal clip first. With lower clip slightly inserted into the frame, align upper clip and alignment ped into frame. Snap switch pod into place. (**Photo 7**)
- 9) Check fitment of new Switch Pod. Trim should fit just to the outside and inside edge of the windshield frame. Reinstall upper windshield trim. Inspect fitment with upper trim in place. Open and close door. If Pod moves, reposition Pod to frame until movement has stopped. (**Photo 8**)