

3101 W. FM 544 Wylie, TX 75098 866.342.0977 BLKMTNJeep.com

Part #BM82209740



READ INSTALLATION INSTRUCTIONS ENTIRELY PRIOR TO INSTALLING PRODUCT

REMOVING STOCK BUMPER:

- 1) Ensure that all components in kit are accounted for.
- 2) Disconnect negative battery cable
- 3) Remove the grille and disconnect the bulbs from the turn signal housings
- 4) Remove the front air dam by removing the four (4) plastic screws on the top and two (2) on the bottom
- 5) Disconnect fog light connector and disconnect harness from bumper if equipped.
- 6) Remove the nuts holding the front bumper to the frame. There are eight (8) nuts, four per side. Retain the front bumper mounting hardware, including the stud plates or tow hooks.
- 7) Carefully remove the front bumper, ensuring that no wiring harness are connected to it.
- 8) Remove the front bumper cover from the top of the frame by removing the two (2) plastic screws.