



Heavy-Duty Tire Carrier
INSTALLATION INSTRUCTIONS

3101 W. FM 544
Wylie, TX 75098
866.342.0977
BLKMTNJeep.com

Part #BM13895



READ INSTALLATION INSTRUCTIONS ENTIRELY PRIOR TO INSTALLING PRODUCT

- 1) Remove vent from inside tailgate & unplug 3rd brake light wire.
- 2) Illustration shown with 35" tire
- 3) Remove plastic grommet from tailgate
- 4) Remove four (4) factory bolts
- 5) Trim pre-installed vent corners to allow clearance for carrier to fit flush against tailgate
- 6) Remove 3rd brake light from factory taillight assembly. Mount directly to HD spare tire carrier (see pic)
- 7) Reuse factory bolts to secure carrier to tailgate
- 8) Use hardware bolt spacers to mount to left & right bars (see pic)

